



Boundary Box	Break Pressure Tank	Capped End	Hydrant
Boundary Box	BPT	Capped End	Emptying Plug
	Break Pressure Tank		Fire Hydrant
			WOH Washout Hydrant
Pressure Monitoring	Service Reservoir	Meter	Valve - Controllable
Logger	Covered	Tower	Meter
			Open Valve
			Closed Valve
			Stop Tap
Site	Valve - Flow		
Abstraction Point	Supply Works	AV Air Valve	NRV Non-Return Valve
Booster Station	Transfer Station	PRV Pressure Reducing Valve	PSV Pressure Sustaining Valve
Surface Reservoir	Underground Source		WO Washout Empty Valve
Water Pipe		Water Area	
Communication	Trunk	Decommissioned	Water Supply Zone
Distribution	Raw		District Meter Area
Non-Potable	Private		

Map Title: SW Print

Printed By: Lia.Loversidge

Date Printed: 15/05/2025

Map Scale: 1:250

The information provided is believed to be correct but is provided on an 'as is' basis and without any warranty or condition express or implied, statutory or otherwise as to its quality or fitness for purpose. Actual positions of assets should always be determined on site.

