



Boundary Box	Break Pressure Tank	Capped End	Hydrant		
 Boundary Box	 BPT Break Pressure Tank	 Capped End	 Emptying Plug	 Fire Hydrant	 WOH Washout Hydrant
Pressure Monitoring	Service Reservoir	Meter	Valve - Controllable		
 Logger	 Covered	 Tower	 Meter	 Open Valve	 Closed Valve
 Abstraction Point	 Supply Works	 AV Air Valve	 NRV Non-Return Valve	 WO Washout Empty Valve	
 Booster Station	 Transfer Station	Valve - Pressure			 Pipe Bridge
 Surface Reservoir	 Underground Source	 PRV Pressure Reducing Valve	 PSV Pressure Sustaining Valve		 Pipe Bridge
Water Pipe			Water Area		
— Communication	— Trunk	— Decommissioned	 Water Supply Zone	 District Meter Area	
— Distribution	— Raw	— Discolouration			
— Non-Potable	— Private				

## Map Title: SW Print

Printed By: Kelly.Donaldson

Date Printed: 10/10/2024

Map Scale: 1:250

*The information provided is believed to be correct but is provided on an 'as is' basis and without any warranty or condition express or implied, statutory or otherwise as to its quality or fitness for purpose. Actual positions of assets should always be determined on site.*

