
T.P. OFFICE COPY

Technical guide

Contractor Manual



TOPSEAL®
GRP FLAT ROOFING

T.P. OFFICE COPY
BOROUGH OF WORTHING
DEPOSITED 5.10.10
TP REF. No.
WR/10/0001/LBY

Contents

Contractor Manual

Contents	Page No.
Datasheet	4
General application information	5
Warm roof specification	6
GRP onto concrete or asphalt	7
A170	8
A200	9
A250	10
B230	11
B260	12
B300	13
C100/ C100MT	14
C200	15
D260	16
E35	17
E280	18
F300	19
G180	20
Corner Trims	21
S500	22
AT195Ext	23
AT195Int	24
Balustrade Support	25
Applying Tiles onto Topseal	26
Mansard Roof Detail	27
Outlet Through Parapet Wall	28
Skylight Installation	29
Parapet Wall (Laid Under Capping Stone)	30
Parapet Wall (Laid Over Capping Stone)	31
Pre-Formed PVC Outlet	32
Roof Ventilator	33
PVC Soil Pipe (or Other Extrusions)	34
Bonding GRP to Metal	35
Pond and Pool Lining	36-37
Hygienic and other Food Contact Linings	38-39
Bund Lining	40
Troubleshooting	41-44

Topseal Systems Ltd
Units 1 - 5
Hookstone Chase
Harrogate
North Yorks
HG2 7HP
T: 01423 888585
F: 01423 888550
www.topseal.co.uk

Datasheet

Product Name: Topseal GRP Roofing

Topseal's single-ply GRP laminate can be installed to any size, in any BS4800 colour and to any degree of complexity, without any seams, welds or joints and it comes with a minimum 20 year protected guarantee.

Standards Compliance

BBA (British Board of Agrément) Certificate Number: 93/2932 (can be viewed online at: www.bbacerts.co.uk)

Resins to BS3532 and BS2782, CSM to BS3496 and colours to BS4800.

Fire retardant to class 1 if required.

Calculated 'U' value = 0.24W/m²K (Calculated in accordance with BS EN ISO 6946 (when laid to 'warm roof' specification.)

Finish Options

Colour range: Topseal is available in a choice of 2 shades of grey as standard: Cool Grey, Dark Admiralty.

Topseal holds a stock of its most popular BS4800 colours (colour chart available on request.) A Topseal roof can be specified in any BS4800 colour.

A Topseal roof can be specified with a non-slip aggregate finish.

Properties and Performance

Weatherightness (Excerpts from BBA certificate.)
The system is impervious to water and, when used in the systems described will give a weatheright roofing capable of accepting minor structural movements without damage.

Resistance to wind uplift
The system has adequate resistance to the effects of wind suction likely to occur within practice.

Properties in relation to fire
A system comprising Topseal applied to an 18mm thick Sterling Board substrate, when tested to BS 476: Part3: 1958, was designated EXT.F.AA.A system comprising Topseal laminate applied to 15mm OSB/3 board when tested to prEN 1187; tests 1, 2 and 3, achieved Classification Broof (t1) Broof (t2) and Broof (t3) respectively.

Durability
A Topseal GRP laminate constructed in accordance with the installation guide and formed in satisfactory weather conditions can be expected to maintain its integrity and show no measurable loss of physical properties for a period of 30 years or more.

Test (Units)	Method	Mean Result
Thickness (mm)	Dial Gauge	1.75
Apparent density (kgm-3)	ISO 1183	1360
Glass/Resin Ratio	BS.2782	3.5:1
Barcol Hardness	BS.2782	35

General information

General application information

Application

A Topseal laminate is constructed from 4 main components: 18mm OSB3 T&G boards, Topseal roofing resin, Topseal 450g/m² Chopped Strand Mat and Topseal Topcoat. The roof is made the Topseal laminate laid in situ over the OSB3 decking constructed as shown below. The resin is applied at a ratio of 3:1 (weight of resin to glass) which gives a practical estimate of 1.5kg per m² when accounting for wastage. Topcoat is applied at a rate of 0.5kg per m². For further direction on the installation of a Topseal roof, refer to the Installation Manual.


Quantity estimation

The values given below are only an estimate and will depend on the complexity of the roof surface. The quantities for decking boards are based on an exact calculation of the area of coverage of each board, in practice, this should be considered a conservative estimate. For a more comprehensive materials estimate please refer to the materials estimation table in the installation manual.

Roof Size (M²)	Topseal Resin (Kg)	Topseal Topcoat (Kg)	Topseal 450g/m² CSM (Kg)	OSB3 T&G Boards (8'X2')
10	15	5	4.5	7
20	30	10	9	14
30	45	15	13.5	21
40	60	20	18	28
50	75	25	22.5	35
60	90	30	27	42
70	105	35	31.5	49
80	120	40	36	56
90	135	45	40.5	63
100	150	50	45	69

Warm and Cold Roof Specification

Topseal can be installed in both a cold or warm roof configuration. A typical cold roof configuration is shown below:



Topseal Systems Ltd
Units 1 - 5
Hookstone Chase
Harrogate
North Yorks
HG2 7HP
T: 01423 888495
F: 01423 888550
www.topseal.co.uk


Warm roof specification


Application instructions

A warm roof can be easily incorporated into a Topseal roof. A sub-deck is first fixed to the joists and should be fixed at 300mm centres. Then a vapour check and insulation sheets can be laid over the top. Insulation sheets can also be bought with a vapour check adhered to one side. The decking should then be laid on top as it normally would be, screws should be used to fix the boards to the joists, these should penetrate through the insulation and into the joists with the same depth as standard fixings. It is imperative that all layers of the roof are pressed firmly together and that there are no gaps between any of the layers. The GRP should then be laminated over the top of the roof as normal. These roofs will usually require larger edge trim sizes such as A250 and B300. To comply with Part L Regulations of Jan 2006 the following specification would be required to obtain a 'U' value of 0.24 installed as shown below:

12mm Ply Sub Deck
85mm of Kingspan TR26 or equivalent
18mm T&G OSB3 board
Topseal Laminate

Cross-section of warm roof onto decking







Warm roof onto concrete or asphalt

Application instructions

When installing a warm roof onto a concrete substrate, it is important that the existing concrete or asphalt layer is completely dry, clean and in good condition. Battens the same thickness as the insulation boards used should be solidly attached to the concrete at 300mm centres. The Sterling board should then be fixed to the battens using the same fixings as would normally be used. Ensure there are no gaps between the layers. The laminate can then be laid over the top as normal.

Cross-section of warm roof onto concrete or asphalt






Technical information

Topseal Systems Ltd
Units 1 - 5
Hookstone Chase
Harrogate
North Yorks
HG2 7HP
T: 01423 888585
F: 01423 888550
www.topseal.co.uk

A170- Fascia trim


Application instructions

The A170 (or Mini A) is designed for applications where it is not possible to use the larger A200. The A170 is a drip trim, fitted to the lowest edge of the roof usually where the rainwater flows into the gutter. The batten for the A170 should be doubled up to provide a stand off for the gutter to fit behind the trim, with the outer batten 10mm lower than the inner batten to allow for the radius of the trim. Apply trim adhesive to the batten in 300mm beads at 300mm centres, rub the trim into place and nail to the decking. Do not nail through the front of the trim. Where the trims are over-lapped, they should be bonded together with a thin strip of PU adhesive on the inside of the overlapping trim. It the pitch of the roof is only minimal, rainwater is likely to be held behind the trim. Use a planning machine to take 2mm off the deck to allow the trim to lay flush with the board. As with all of Topseal's extruded profiles, the A170 is supplied in 3 metre lengths.



A170


A170 typical application



A200- Fascia trim


Application instructions

The A200 is compatible with C1, C2 & C4 universal corners. The A200 is a drip trim, fitted to the lowest edge of the roof usually where the rainwater flows into the gutter. The batten for the A200 should be doubled up to provide a stand off for the gutter to fit behind the trim, with the outer batten 10mm lower than the inner batten to allow for the radius of the trim. Apply trim adhesive to the batten in 30mm beads at 300mm centres, rub the trim into place and nail to the decking. Do not nail through the front of the trim. Where the trims are over-lapped, they should be bonded together with a thin strip of PU adhesive on the inside of the overlapping trim. It the pitch of the roof is only minimal, rainwater is likely to be held behind the trim. Use a planning machine to take 2mm off the deck to allow the trim to lay flush with the board. As with all of Topseal's extruded profiles, the A200 is supplied in 3 metre lengths.



A200

A200 typical application




Technical information

Topseal Systems Ltd
Units 1 - 5
Hookstone Chase
Harrogate
North Yorks
HG2 7HP
T: 01423 886495
F: 01423 885550
www.topseal.co.uk

A250- Fascia trim


Application instructions

The A250 is designed to cover insulation so is ideally suited to use with warm roofs and has an extra deep fascia to allow gutter penetration. The A250 is a drip trim, fitted to the lowest edge of the roof usually where the rainwater flows into the gutter. The batten for the A250 should be doubled up to provide a stand off for the gutter to fit behind the trim, with the outer batten 10mm lower than the inner batten to allow for the radius of the trim. Apply trim adhesive to the batten in 30mm beads at 300mm centres, rub the trim into place and nail through the front of the trim. Where the trims are over-lapped, they should be bonded together with a thin strip of PU adhesive on the inside of the overlapping trim. Do not nail through the front of the trim. Where the trims are over-lapped, they should be bonded together with a thin strip of PU adhesive to only minimal, rainwater is likely to be held behind the trim. Use a planning machine to take 2mm off the deck to allow the trim to lay flush with the board. As with all of Topseal's extruded profiles, the A250 is supplied in 3 metre lengths.



A250


A250 typical application



B230- Raised edge trim


Application instructions

The B230 is an up-stand trim, fitted to contain and direct the flow of water to a gutter. A single batten is fixed level with the top edge of the deck. Apply 30mm beads of trim adhesive to the batten at 300mm centres, rub the trim into place and nail through the top of the trim into the decking. Do not nail through the front of the trim. Where the trims are over-lapped, they should be bonded together with a thin strip of PU adhesive on the inside of the overlapping trim. If a ladder is likely to be leant against a B type trim for access to the roof, the trim will need to be reinforced to avoid deformation. The trim can either be doubled up by slotting a section of extra trim within the area where the ladder will be used or it can be reinforced with an extra layer of GRP laminate and then tissue to maintain a smooth finish. Alternately, a wooden batten can be shaped and fitted into the ridge of the trim to ensure that it remains rigid.



B230

B230 typical application




Technical information

Topseal Systems Ltd
Units 1 - 5
Hookstone Chase
Harrogate
North Yorks
HG2 7HP
T: 01423 888495
F: 01423 888550
www.topseal.co.uk

B260- Raised edge trim


Application instructions

The B260 is compatible with C1, C2 & C4 universal corners. The B230 is an up-stand trim, fitted to contain and direct the flow of water to a gutter. A single batten is fixed level with the top edge of the deck. Apply 30mm beads of trim adhesive to the batten at 300mm centres, rub the trim into place and nail through the top of the trim into the decking. Do not nail through the front of the trim. Where the trims are over-lapped, they should be bonded together with a thin strip of PU adhesive on the inside of the overlapping trim. If a ladder is likely to be leant against a B type trim for access to the roof, the trim will need to be reinforced to avoid deformation. The trim can either be doubled up by slotting a section of extra trim within the section where the ladder will be used or it can be reinforced by being coated with a layer of GRP laminate and then tissue to maintain a smooth finish. Alternately, a wooden batten can be shaped and fitted into the ridge of the trim to ensure that it remains rigid.



B260


B260 typical application



B300- Raised edge trim


Application instructions

The B300 is an up-stand trim, fitted to contain and direct the flow of water to a gutter, its extra depth is well-suited to use on a warm roof to allow for deep gutter penetration. A single batten is fixed level with the top edge of the deck. Apply 30mm beads of trim adhesive to the batten at 300mm centres, rub the trim into place and nail through the top of the trim into the decking. Do not nail through the front of the trim. Where the trims are over-lapped, they should be bonded together with a thin strip of PU adhesive on the inside of the overlapping trim. If a ladder is likely to be leant against a B type trim for access to the roof, the trim will need to be reinforced to avoid deformation. The trim can either be doubled up by slotting a section of extra trim within the section where the ladder will be used or it can be reinforced by being coated with a layer of GRP laminate and then tissue to maintain a smooth finish. Alternately, a wooden batten can be shaped and fitted into the ridge of the trim to ensure that it remains rigid.



B300

B300 typical application




Technical information

Topseal Systems Ltd
Units 1 - 5
Hookstone Chase
Harrogate
North Yorks
HG2 7HP
T: 01423 888495
F: 01423 888550
www.topseal.co.uk


C100\C100MT- Simulated lead flashing

Application instructions

The C100 is a simulated lead flashing, generally fitted in conjunction with D260 angle fillet trim. The C100MT is a simulated lead flashing with an integral, self-securing moisture trap. C100\MT is usually fitted into a bed joint of the brickwork or a 25mm deep slot cut out with an angle grinder fitted with a motor chase disc. Apply Topseal trim adhesive to the back of the trim at 300mm centres. Fit the trim into the slot and press firmly back to the wall. Apply a clear silicone sealant along the length of the C100\MT into the slot.




C100 typical application




C200- Simulated lead flashing with moisture trap

Application instructions

The C200 is a simulated lead flashing, generally fitted in conjunction with D260 angle fillet trim. The C200 is used for applications where the flashing needs to be fitted higher up in the brickwork where a C100 cannot be used. The trim is usually fitted into a bed joint of the brickwork or a 25mm deep slot cut out with an angle grinder fitted with a motor chase disc. Apply Topseal trim adhesive to the back of the trim at 300mm centres. Fit the trim into the slot and press firmly back to the wall. Apply a clear silicone sealant along the length of the C200 into the slot to seal it into the wall.



C200 typical application



Technical information


Topseal Systems Ltd
Units 1 - 5
Hookstone Chase
Harrogate
North Yorks
HG2 7HP
T: 01423 886495
F: 01423 888550
www.topseal.co.uk

Technical information

Torbeck Systems Ltd
Unit 1 - 2
Hookstone Chase
Harrogate
North Yorks
HG3 1HH
T: 01423 888888
F: 01423 888020
www.torbeck.co.uk

E32 - Simulated rolled lead joint


E32 typical application



Application instructions


Used to simulate the appearance to raised rolled lead joints, also provides expansion. The trim should be nailed to the deck to 300mm centres. The joint and nail penetrations should be pandaged before the laminate is laid over the top of the trim.

Ensure that the laminate is well conditioned over the top of the trim.




D250 - Wall fillet

D250 typical application



Application instructions


The D250 is an angle fillet trim, fitted where the roof abuts a wall or vertical face, ideally between parapet walls, in pox gutters etc. It is compatible with C2 and C3 universal corners. An angle fillet generally does not require a pattern or to be bonded with trim adhesive. Place the trim upright the vertical face and push down diagonally into the corner run fillet trim fit snugly. Where the trims are over-lapped they should be bonded with trim adhesive and pandaged together.



E280- Raised ridge roll


Application instructions

E280 is used both to create expansion joints on large roofs (over 50m²) and create rolls on any ridge details. It is compatible with C6 closures. An adequate gap in the deck should be cut if necessary, the trim should then be rolled to each end of the decking at 300mm centres. The join over the rolls should then be bonded and the laminate should be applied over the trim. To bond these trims together, or to cap with C6 closures, apply a thin strip of PU adhesive to the inside edge of the overlapping trim and rub into place.



E280


E280 typical application



F300- Flat flashing


Application instructions

The F300 is a flat flashing, mainly used at the intersection of a pitched roof and flat roof often found on dormers. F300 should always be used for this situation and it should NOT be laminated as this will be a weak point and it will crack. It is nailed or stapled to the deck and bent up the roof slope. In this situation, the F300 also acts as an expansion facility and must only be fixed along the bottom edge. There are many other applications for F300 including vertical details where laminating would be time consuming, under the feet of air conditioning units to enable re-roofing without disconnecting, some parapet wall details etc. The F300 can be bent to adapt it to most applications which require a flexible flat sheeting. The trim should be nailed to the deck ground its edges and bandaged over any joins or nail penetrations. Any unlaminated trim can be topcoated with the rest of the roof.



F300

F300 typical application



Technical information

Topsail Systems Ltd
Units 1 - 5
Hookstone Chase
Harrogate
North Yorks
HG2 7HP
T: 01423 886495
F: 01423 888550
www.topsail.co.uk

Technical information

Topseal Systems Ltd
Unit 1 - 2
Hookstone Chase
Harrogate
North Yorks
HG3 1HH
T: 01423 888444
F: 01423 888220
www.topseal.co.uk

C1,2,3,4,5,6 -Corners and closures

Application instructions- Corners

Application is the same for all the corner units listed below. The corner should be bolted through the overlapping trim to trim with a trim to the deck to each end and fit the middle. The joins between the trim and the corner should be sealed with a trim to Topseal trim adhesive, a moist finger can be used to wipe the adhesive, ensuring it seals the entire joint. The joint is then pressed down to ensure a smooth finish.

Corner trim range

C1 Universal external corner- Compatible with A500 and B540 when used on an aluminium edge.

C2 Universal internal corner- Compatible with A500 & B540.


C3 Internal/External fillet corner- Preformed internal/external corner for use with DS40. Avoids mitring in situ.


C4 Universal internal corner- Pre-formed internal left and right hand corners . Compatible with A500 & B540.


C5 Fillet to trim corner- For at junction of flat roof and upstand wall. Compatible with A500, B540 & DS40.

C6 Rolled up closure- Compatible with E32 internal/high trim.

C7 Foot high closure- Compatible with ES40 expansion joint\high trim.







C180- Expansion joint


Application instructions

C180 is used to allow for expansion on large roof (over 20m) ft also acts as an integral gutter to bla drainage. The decking should be cut to allow for an overlap of 1inch to front the trim. the flanges to the trim should be installed with the decking. The trim should then be bolted to the decking. The joins between where the trim edges are bolted and the decking should then be bonded with the laminate should be applied over the trim.

Technical information


Topseal Systems Ltd
Units 1 - 5
Hookstone Chase
Harrogate
North Yorks
HG2 7HP
T: 01423 888488
F: 01423 889250
www.topseal.co.uk

AT 19S External angle trim




Application instructions

The AT19S external trim is used wherever the Topseal laminate needs to cover a surface which needs to continue perpendicular to the current level. The trim is supplied with a high adhesion finish on its outer facia. The trim should be nailed at both edges if possible. Always bandage over the join between where the nails penetrate the trim and the decking before applying the laminate.




5500- Soffit trim



Application instructions


Used as a fascia trim for concrete roofing or any similar application which requires an over-sized soffit trim. A support batten should be attached to the wall beneath the structure. The trim should be nailed to the decking and then the underside should be nailed to the batten. The join between where the nails penetrate the trim and centres. Always bandage over the join between where the laminate needs to continue the decking should be bandaged over, the laminate can then be applied to the roof and should over the bandage. The laminate should not extend onto the fascia of the trim.



AT 195 Internal angle trim


Application instructions


The AT195 external trim is used wherever the Topseal laminate needs to cover a surface which needs to continue perpendicular to the current level. The trim is supplied with a high adhesion finish on its outer face. The trim should be nailed at both edges if possible. Always bandage over the join between where the nails penetrate the trim and the decking before applying the laminate.



AT 195 Int

AT195 Int typical application







Balustrade support fixing

Application instructions

Balustrade supports fixings can be installed onto a completed Topseal laminate after it has cured. The timber plinth is laminated to the substrate and then topcoated. The balustrade is then screwed into the plinth and the wholes and area around the screws are completely sealed with PU adhesive. Always ensure the roof area on which the fixing will be laminated is clean, dry and free from debris, wiping the surface down with acetone will help to remove any contaminants present in the laminate. It may help to clean and abrade the surface with medium grade sand paper before wiping with acetone to increase the inter laminar adhesion.



Mansard support typical application




Topseal Systems Ltd
Units 1 - 5
Hookstone Chase
Harrogate
North Yorks
HG2 7HP
T: 01423 888488
F: 01423 888550
www.topseal.co.uk

Technical information


Outlet through parapet wall

Application instructions

The pre-formed GRP outlet lining should be constructed as the trims are fixed to the roof. Two D260s can be joined together using a piece of laminated bandage to seal the joint after the trims have been fixed securely to the decking using clout nails. An A type drip trim should be used to allow water to flow into the gutter. The decking should be rebated by 2mm to allow the A trim to sit level with the roof and prevent water from ponding in the outlet.




Outlet through parapet.




Rooflight installation

Application instructions

Pre-formed skylight units can be easily incorporated into a Topseal roof. As a general rule, the skylight should be fixed to the structure the roof is to be laid onto by either rolling or some other mechanical form of fixing. The flanges of the frame should then be bandaged over where it is attached to the structure. The laminate should be laid up to the edge of the skylight. If the skylight requires a frame to be constructed, this should be also be incorporated into a structure.



Outlet through parapet.




Technical information

Topseal Systems Ltd
Units 1 - 5
Hookstone Chase
Harrogate
North Yorks
HG2 7HP
T: 01423 888495
F: 01423 888550
www.topseal.co.uk


Parapet wall (laid under capping stone)

Application instructions

A parapet wall should usually be incorporated into the roof to prevent any porosity arising from any tailings in the wall. The wall can either be covered completely, or it can be dressed into the wall and capping stones can be fixed on after the roof has cured. In this case, the roof is laid under the dapping stone. F300 should be mechanically fixed to the wall and sealed around the perimeter with PU adhesive. The roof can then be laid on top. A suitable non-cementatious adhesive can then be used to fix the stone on top of the wall.




Parapet wall (laid under capping stone.)




Parapet wall (laid over capping stone.)

Application instructions

A parapet wall should usually be incorporated into the roof to prevent any porosity arising from any tailings in the wall. The wall can either be covered completely, or it can be dressed into the wall and capping stones can be fixed on after the roof has cured. In this case, the roof is laid over the dapping stone. The trims used are all nailed to the decking and bandaged before the laminate is laid over the top.



Parapet wall (laid under capping stone.)



Technical information


Topseal Systems Ltd
Units 1 - 5
Hookstone Chase
Harrogate
North Yorks
HG2 7HP
T: 01423 888466
F: 01423 888550
www.topseal.co.uk

Pre-formed PVC pipe outlet


Application instructions

The outlet should be constructed before the roof is laid. Place a suitable PVC pipe of a polished glass street and apply a bead of PU adhesive around the outside of the pipe at least 100mm from the base of the pipe. Lay the laminate up around the outside of the pipe and ensure it is thoroughly consolidated into the PU and sealed around the pipe. Apply enough laminate around the bottom of the pipe to form a base that can later be nailed to the deck. The pipe can be fitted in place when the remaining trims are fitted to the roof. The outlet should be nailed to the decking around its perimeter and incorporated into the laminate.


Forming the outlet



Fitting the outlet into the roof



Pre-formed PVC pipe outlet




Forming the outlet

Fitting the outlet into the roof


Roof Ventilator

Application instructions

A pre-formed roof ventilator can be easily incorporated into a Topseal roof. A gap should be left in the decking where the ventilator is required. While the trims are being fixed to the roof, the ventilator can be nailed in place. The join should be bandaged and the laminate can be laid over the top of the base.



Roof ventilator




Topseal Systems Ltd
Units 1 - 5
Hookstone Chase
Harrogate
North Yorks
HG2 7HP
T: 01423 886656
F: 01423 886550
www.topseal.co.uk


PVC soil pipe (or other extrusions)

Application instructions

The same procedure can be used for all extrusions on a roof. First cut a piece of F300 flat sheeting to fit around the extrusion nail it to the deck and seal only gaps with a bead of PU adhesive. Bandage over the joins in the sheeting and around the base of the extrusion. When laying the roof, ensure that the laminate extends up the base of the pipe.



Pre-formed PVC pipe outlet



Bonding GRP to metal


Application instructions

Polyester resins are poor adhesives and rely on the porosity of the substrate to affect a good bond, the bond to metals is poor. There is also the additional problem of differential expansion due to the difference of the coefficient of expansion between steel and GRP.

To overcome this problem there needs to be a good bond between the GRP and metal substrate which will remain flexible and tolerate the differential movement between the two dis-similar materials.

This can be achieved by using a moisture cured PU adhesive sealant trapped between the 2 materials as shown below:

Bonding GRP to metal



Preparation

Thoroughly clean the metal surface to be bonded onto. Remove all paint, rust etc., and ensure that the surface is clean and dry. It is best to wipe the surface with acetone to ensure no contamination.

Application

Using a skeleton gun, gun apply generous beads of PU adhesive onto the metal to be over-laminated. Where water will be running over this bonded area, or if this area is to be submerged, use 2 or 3 parallel beads in order to ensure complete sealing round the perimeter.

Immediately apply the CSM to the surface of the beads and rub into place. A more effective seal may be achieved by using a small consolidation roller to ensure that the adhesive is fully consolidated into the glass.

Leave to cure for about 2 hours. The PU is moisture cured and the curing reaction must finish before the laminate is applied over the top of the CSM. Apply resin to the CSM and form a laminate.

Topseal Systems Ltd
Units 1 - 5
Hookstone Chase
Harrogate
North Yorks
HG2 7HP
T: 01423 888488
F: 01423 888550
www.topseal.co.uk

GRP is widely used for the manufacture of tanks, garden pools and swimming pools. It will give an inert, hard wearing, long lasting, waterproof skin, that will withstand ground movement and allow the use of aggressive cleaning techniques without danger of damage to the lining.

The technique involves the formation of a GRP laminate in situ using chopped strand mat reinforcement and suitable polyester resin and topcoat pigmented in any BS 4800 colour.

Important considerations when applying Topseal to a pond or pool lining

It is essential that only Topseal resins and topcoats are used to ensure that no residual taint occurs which may affect the contents of the lining. It is also vitally important that the laminate is allowed to cure completely before it comes into contact with water.

Always use summer catalyst when curing any resin or topcoat used for the lining, this gives a more consistant cure than winter catalyst and will give more predictable results.

Preparation

A Topseal laminate can be applied to a concrete or masonry structure. It is important that the stonework is clean, dry and fully set. Any imperfections in the structure with be telegraphed through to the finished surface and may manifest themselves as weaknesses in the finished lining.


Before the laminate can be applied any angles in the structure need to be rounded off and it must be primed with G4 PU primer.

Corner Preparation

Rounding and smoothing off the corners makes the laminate easier to lay, it reduces any points of weakness and stress on the laminate and also makes the finished lining easier to clean. Sharp angles are filleted using Topseal resin mixed with an inert filler, this can be slate dust, talk or chalk. Do not use cement or plaster as a filler, these substances are alkaline and will kill the cure if the laminate is laid on to them.

The filler is mixed at a ratio of 1 part Topseal catalysed resin to 4 parts inert filler.

When the catalysed resin filler has been mixed it can be applied to any sharp angles of the pond. A brush soaked with catalysed resin can then be used to smooth off the compound and give a finish ready to laminate.



Application

The concrete surface should be primed with G4 primer. This is a moisture cured polyurethane coating that should be allowed to partially cure before applying the first coat of resin. If the primer is allowed to fully cure it will act as a release agent and the GRP layer will not bond. If the primer has fully cured it will need to be reapplied.

Apply catalysed resin to the tacky PU primer. The resin may then be allowed to cure before laying down the main laminates if the structure is too large to line in one session.

Firstly, all of the areas of highest stress should be bandaged, this includes all sharp angles, areas that have been treated with filled resin compound and steps, etc. It is vital to ensure that the GRP is applied to the surface without any air gaps or spaces remaining so it must be well consolidated. As with the main laminate, use a low reactivity catalyst (i.e. summer or LPT) at between 1 & 2%. Lay two 450g/m2 laminates onto the structure ensuring that they are both well consolidated. Lay the second laminate over the first while it is still uncured to increase inter-laminar adhesion. The laminate can be dressed around the perimeter pool with the use of capping stones (see portrait walls on page xx) which can be adhered to the laminate with PU adhesive, alternatively, a steel edging strip can be used. The laminate and stone structure of a pool should continue over the side of the pool and onto a flat surround to allow the laminate to be dressed over the side of the structure.

Depending on the quality of the finish required, the laminate may be finished with surface tissue and lightly abraded with medium grade sand paper when cured to ensure a smooth finish.

Pigmented topcoat can then be applied to the laminate using no more than 1-2% low reactivity catalyst. Pigment addition should be no more than 10%. Is is advisable to use only darker colours in pond applications. Where the topcoat is in permenant contact with water, 2 thin applications of topcoat can be used to give a perfect finish. The topcoat thickness should generally not exceed 0.5mm.

Always exercise caution when applying resin or topcoat in very hot weather by using LPT catalyst. Avoid applying the topcoat in very hot direct sunlight as this can lead to 'tacky' topcoat.

Dark grey topcoat pigment normally gives the best appearance in a pool.

Curing the laminate

It is essential that the laminate is allowed to cure completely before it comes into any contact with any water. This avoids any taint of the water and 'staining' of the topcoat. The pool/pond should be kept completely dry by erecting a 'tent' or sheet over the top of the pool. In summer the sheet needn't be used when dry weather is forecast and the heat from the sun will assist the curing process. Otherwise a 1KW fan heater should be placed in the pool under the tent to heat the surface of the laminate. It is important that a fan heater is used, as the heat should be circulated over the surface.

No attempt should be made to fill the pool for two weeks after the topcoat has been applied. It is vital that the laminate is left to fully cure during this period. If the pool does get wet and 'staining' of the topcoat occurs it can be removed by 'cutting back' the laminate with T-Cut or Brasso. When this period or longer has passed the pool should be filled with a hose pipe and the water left to overflow for a period of 2 hours before the pond or pool is used. This process ensures that any surface wax or other debris is carried away with the overflowing water.

Topseal Systems Ltd
Units 1 - 5
Hookstone Chase
Harrogate
North Yorks
HG2 7HP
T: 01423 888495
F: 01423 888550
www.topseal.co.uk

Technical information

Hygienic and other food contact linings

GRP can be used for a wide variety of different hygienic and food contact linings in any number of scenarios including kitchens, abbatoirs, farms and food transportation vehicles. It will give an inert, hard wearing, long lasting, waterproof skin, that will withstand ground movement and allow the use of aggressive cleaning techniques without danger of damage to the lining.

The technique involves the formation of GRP laminate in situ using chopped strand mat reinforcement and suitable polyester resin and topcoat pigmented to any BS 4800 colour.

Important considerations when applying Topseal to a pond or pool lining

It is essential that only Topseal resins and topcoats are used to ensure that no residual taint occurs that may affect the contents of the lining. It is also vitally important that the laminate is allowed to cure completely before it comes into contact with water.


Always use summer catalyst when curing any resin used for the lining, this gives a more consistant cure than winter catalyst and will give more predictable results.

Preparation

A Topseal laminate can be applied to a concrete or masonry structure. It is important that the stonework is clean, dry and fully set. Any imperfections in the structure will be telegraphed through to the finished surface and may manifest themselves as weaknesses in the finished lining.

Before the laminate can be applied any angles in the structure need to be rounded off and it must be primed with G4 PU primer.

Corner Preparation



The filled resin compound is applied to all sharp angles in the structure to give smooth filleted corners.

Rounding and smoothing off the corners makes the laminate easier to lay, it reduces any points of weakness and stress on the laminate and also makes the finished lining easier to clean. Sharp angles are filleted using Topseal resin mixed with an inert filler, this can be slate dust, talk or chalk. Do not use cement or plaster as a filler as these substances are alkaline and will kill the cure in the laminate laid on to them.

The filler is mixed at a ratio of 1 part Topseal catalysted resin to 4 parts inert filler.

When the catalysed resin filler has been mixed it can be applied to any sharp angles of the pond. A brush of catalysed resin can then be used to smooth off the compound and give a finish ready to laminate.

Application

The concrete surface should be primed with G4 primer. This is a moisture cured polyurethane coating that should be allowed to partially cure before applying the first coat of resin. If the primer is allowed to fully cure it will act as crelease agent and the GRP layer will not bond.

Apply catalysed resin to the tacky PU primer. The resin may then be allowed to cure before laying down the main laminates if the structure is too large to line in one session.

Firstly, all of the areas of highest stress should be bandaged, this includes all sharp angles, areas that have been treated with filled resin compound and steps, etc. It is vital to ensure that the GRP is applied to the surface without any air gaps or spaces remaining so it must be well consolidated. As with the main laminate use only Topseal resins with a low reactivity catalyst (i.e. summer or LPT) at between 1 & 2%.

The structure can be laminated with either 2 x 450g/m² laminates or 1 x 600g/m² laminate depending on the required usage of the areas. If applying two laminates, lay the second laminate over the first while it is still uncured to increase inter-laminar adhesion.

Depending on the quality of surface finish required, the laminate may be finished with surface tissue and lightly abraded with medium grade sand paper when cured to ensure a smooth finish.

Hygienic and other food contact linings

Pigmented topcoat can then be applied to the laminate using no more than 1-2% low reactivity catalyst. Pigment addition should be no more than 10%. Where the topcoat is in permenant contact with water, 2 thin applications of topcoat can be used to give a perfect finish. The topcoat thickness should generally not exceed 0.5mm.

Curing the laminate

It is essential that the laminate is allowed to cure completely before it comes into any contact with any moisture or water. This avoids any taint to anything kept in the area and 'staining' of the topcoat. The room or area should not be used until the laminate is completely cured. The curing regime should ideally involve heating the root up to 60°C with high output fan heaters ensuring the air is circulated around the room. This should be continued for 24 hours, the room should then be thoroughly ventilated without heat opening all windows, doors etc. and expelling all of the air that has been in the room. The process should then be repeated for another 24 hours at 60°C.

After this the room should not be used before one week since the topcoat was applied.

If the 60°C temperature can not be obtained then the room should be heated as much as possible, using central heating, fan heaters etc. It is still important in this circumstance that the heat is circulated around the room using fans if necessary. After 24 hours at maximum heat the room should be completely ventilated and the process repeated 3 more times. Again, the room should not be used within one week since the topcoat was applied.

Topseal Systems Ltd
Units 1 - 5
Hookstone Chase
Harrogate
North Yorks
HG2 7HP
T: 01423 888488
F: 01423 888550
www.topseal.co.uk

Bund lining

GRP has been used successfully for lining both fuel storage, water and chemical storage areas.

For chemical and solvent storage it is important to ascertain the storage temperature and concentration of the chemical to be contained. For very aggressive alkaline preparations (bleach) a high performance resin or top coat may be specified. Generally, Topseal's standard GRP roofing materials are perfectly good for this application and will easily withstand occasional contact with the stored chemical, but, more importantly, withstand all the mechanical wear and tear that may take place within the bund area for general maintenance etc. It is also important to remember that the bund lining must withstand UV degradation since it must retain its integrity for the life of the installation.

Preparation

The entire floor and wall area within the bund must be clean and dry, and free of other surface preparations.

The entire surface area should be coated with a moisture cured PU (our G4 primer) and allowed to partially cure for 2-4 hours.

Application

The initial resin application should then be applied directly to the partly cured PU and allowed to cure.

The laminate can consist either 1 X 600g/m² laminate or 2 x 450g/m². Laminations should then be applied to the prepared surface in clean, dry conditions, ensuring that all surface details, pipework and drain outlets are sealed or fully lined with GRP.

The top coat should be applied to the GRP layer within 4 hours of the initial cure. A non-slip finish may be included into areas where foot traffic is anticipated, especially if lubricants may be used or spilled within the bund.

The final topcoat coating should be applied to the laminate within 4 hours of the initial cure (any BS4800 colour can be specified.) A non-slip finish may be incorporated into areas where foot traffic is anticipated, especially if lubricants may be used or spilled within the bund.

The laminate may be sept or cleaned with a cold or hot pressure washer. Steam cleaning should be avoided.

The Topseal layer may be modified or repaired as required and should be inspected after a spillage of the stored chemical into the bund area.

Water may be allowed to accumulate in the bund area without any detriment to the Topseal layer.

GRP is widely used for the manufacture of tanks, garden pools and swimming pools. It will give an inert, hard wearing, long lasting, waterproof skin, that will withstand ground movement and allow the use of aggressive cleaning techniques without danger of damage to the lining.

The technique involves the formation of a GRP laminate in situ using chopped strand mat reinforcement and suitable polyester resin and topcoat pigmented in any BS 4800 colour.

Important considerations when applying Topseal to a pond or pool lining

It is essential that only Topseal resins and topcoats are used to ensure that no residual taint occurs which may affect the contents of the lining. It is also vitally important that the laminate is allowed to cure completely before it comes into contact with water.

Always use summer catalyst when curing any resin or topcoat used for the lining, this gives a more consistant cure than winter catalyst and will give more predictable results.

Preparation

A Topseal laminate can be applied to a concrete or masonry structure. It is important that the stonework is clean, dry and fully set. Any imperfections in the structure with be telegraphed through to the finished surface and may manifest themselves as weaknesses in the finished lining.


Before the laminate can be applied any angles in the structure need to be rounded off and it must be primed with G4 PU primer.

Corner Preparation

Rounding and smoothing off the corners makes the laminate easier to lay, it reduces any points of weakness and stress on the laminate and also makes the finished lining easier to clean. Sharp angles are filleted using Topseal resin mixed with an inert filler, this can be slate dust, talk or chalk. Do not use cement or plaster as a filler, these substances are alkaline and will kill the cure if the laminate is laid on to them.

The filler is mixed at a ratio of 1 part Topseal catalysed resin to 4 parts inert filler.

When the catalysed resin filler has been mixed it can be applied to any sharp angles of the pond. A brush soaked with catalysed resin can then be used to smooth off the compound and give a finish ready to laminate.



The filled resin compound is applied to all sharp angles in the structure to give smooth filleted edges.

Application

The concrete surface should be primed with G4 primer. This is a moisture cured polyurethane coating that should be allowed to partially cure before applying the first coat of resin. If the primer is allowed to fully cure it will act as release agent and the GRP layer will not bond. If the primer has fully cured it will need to be reapplied.

Apply catalysed resin to the tacky PU primer. The resin may then be allowed to cure before laying down the main laminates if the structure is too large to line in one session.

Firstly, all of the areas of highest stress should be bandaged, this includes all sharp angles, areas that have been treated with filled resin compound and steps, etc. It is vital to ensure that the GRP is applied to the surface without any air gaps or spaces remaining so it must be well consolidated. As with the main laminate, use a low reactivity catalyst (i.e. summer or LPT) at between 1 & 2%. Lay two 450g/m2 laminates onto the structure ensuring that they are both well consolidated. Lay the second laminate over the first while it is still uncured to increase inter-laminar adhesion. The laminate can be dressed around the perimeter pool with the use of capping stones (see parapet walls on page xx) which can be adhered to the laminate with PU adhesive, alternatively, a steel edging strip can be used. The laminate and stone structure of a pool should continue over the side of the pool and onto a flat surround to allow the laminate to be dressed over the side of the structure.

Depending on the quality of the finish required, the laminate may be finished with surface tissue and lightly abraded with medium grade sand paper when cured to ensure a smooth finish.

Pigmented topcoat can then be applied to the laminate using no more than 1-2% low reactivity catalyst. Pigment addition should be no more than 10%. Is is advisable to use only darker colours in pond applications. Where the topcoat is in permenant contact with water, 2 thin applications of topcoat can be used to give a perfect finish. The topcoat thickness should generally not exceed 0.5mm.

Always exercise caution when applying resin or topcoat in very hot weather by using LPT catalyst. Avoid applying the topcoat in very hot direct sunlight as this can lead to 'tacky' topcoat.

Dark grey topcoat pigment normally gives the best appearance in a pool.

Curing the laminate

It is essential that the laminate is allowed to cure completely before it comes into any contact with any water. This avoids any taint of the water and 'staining' of the topcoat. The pool/pond should be kept completely dry by erecting a 'tent' or sheet over the top of the pool. In summer the sheet needn't be used when dry weather is forecast and the heat from the sun will assist the curing process. Otherwise a 1KW fan heater should be placed in the pool under the tent to heat the surface of the laminate. It is important that a fan heater is used, as the heat should be circulated over the surface.

No attempt should be made to fill the pool for two weeks after the topcoat has been applied. It is vital that the laminate is left to fully cure during this period. If the pool does get wet and 'staining' of the topcoat occurs it can be removed by 'cutting back' the laminate with T-Cut or Brasso. When this period or longer has passed the pool should be filled with a hose pipe and the water left to overflow for a period of 2 hours before the pond or pool is used. This process ensures that any surface wax or other debris is carried away with the overflowing water.

Topseal Systems Ltd
Units 1 - 5
Hookstone Chase
Harrogate
North Yorks
HG2 7HP
T: 01423 886495
F: 01423 888550
www.topseal.co.uk

Technical information

Hygienic and other food contact linings

GRP can be used for a wide variety of different hygienic and food contact linings in any number of scenarios including kitchens, abbatoirs, farms and food transportation vehicles. It will give an inert, hard wearing, long lasting, waterproof skin, that will withstand ground movement and allow the use of aggressive cleaning techniques without danger of damage to the lining.

The technique involves the formation of GRP laminate in situ using chopped strand mat reinforcement and suitable polyester resin and topcoat pigmented to any BS 4800 colour.

Important considerations when applying Topseal to a pond or pool lining

It is essential that only Topseal resins and topcoats are used to ensure that no residual taint occurs that may affect the contents of the lining. It is also vitally important that the laminate is allowed to cure completely before it comes into contact with water.


Always use summer catalyst when curing any resin used for the lining, this gives a more consistant cure than winter catalyst and will give more predictable results.

Preparation

A Topseal laminate can be applied to a concrete or masonry structure. It is important that the stonework is clean, dry and fully set. Any imperfections in the structure will be telegraphed through to the finished surface and may manifest themselves as weaknesses in the finished lining.

Before the laminate can be applied any angles in the structure need to be rounded off and it must be primed with G4 PU primer.

Corner Preparation



Rounding and smoothing off the corners makes the laminate easier to lay, it reduces any points of weakness and stress on the laminate and also makes the finished lining easier to clean. Sharp angles are filleted using Topseal resin mixed with an inert filler, this can be slate dust, talk or chalk. Do not use cement or plaster as a filler as these substances are alkaline and will kill the cure in the laminate laid on to them.

The filler is mixed at a ratio of 1 part Topseal catalysted resin to 4 parts inert filler.

When the catalysed resin filler has been mixed it can be applied to any sharp angles of the pond. A brush of catalysed resin can then be used to smooth off the compound and give a finish ready to laminate.

Application

The concrete surface should be primed with G4 primer. This is a moisture cured polyurethane coating that should be allowed to partially cure before applying the first coat of resin. If the primer is allowed to fully cure it will act as a release agent and the GRP layer will not bond.

Apply catalysed resin to the tacky PU primer. The resin may then be allowed to cure before laying down the main laminates if the structure is too large to line in one session.

Firstly, all of the areas of highest stress should be bandaged, this includes all sharp angles, areas that have been treated with filled resin compound and steps, etc. It is vital to ensure that the GRP is applied to the surface without any air gaps or spaces remaining so it must be well consolidated. As with the main laminate use only Topseal resins with a low reactivity catalyst (i.e. summer or LPT) at between 1 & 2%.

The structure can be laminated with either 2 x 450g/m^2 laminates or 1 x 600g/m^2 laminate depending on the required usage of the areas. If applying two laminates, lay the second laminate over the first while it is still uncured to increase inter-laminar adhesion.

Depending on the quality of surface finish required, the laminate may be finished with surface tissue and lightly abraded with medium grade sand paper when cured to ensure a smooth finish.

Hygienic and other food contact linings

Pigmented topcoat can then be applied to the laminate using no more than 1-2% low reactivity catalyst. Pigment addition should be no more than 10%. Where the topcoat is in permenant contact with water, 2 thin applications of topcoat can be used to give a perfect finish. The topcoat thickness should generally not exceed 0.5mm.

Curing the laminate

It is essential that the laminate is allowed to cure completely before it comes into any contact with any moisture or water. This avoids any taint to anything kept in the area and 'staining' of the topcoat. The room or area should not be used until the laminate is completely cured. The curing regime should ideally involve heating the room to up to 60°C with high output fan heaters ensuring the air is circulated around the room. This should be continued for 24 hours, the room should then be thoroughly ventilated without heat opening all windows, doors etc. and expelling all of the air that has been in the room. The process should then be repeated for another 24 hours at 60°C.

After this the room should not be used before one week since the topcoat was applied.

If the 60°C temperature can not be obtained then the room should be heated as much as possible, using central heating, fan heaters etc. It is still important in this circumstance that the heat is circulated around the room using fans if necessary. After 24 hours at maximum heat the room should be completely ventilated and the process repeated 3 more times. Again, the room should not be used within one week since the topcoat was applied.

Topseal Systems Ltd
Units 1 - 5
Hookstone Chase
Harrogate
North Yorks
HG2 7HP
T: 01423 886495
F: 01423 888550
www.topseal.co.uk

Topseal Systems Ltd.
Units 1-5 Hookstone Chase
Harrogate
HG2 7HP
01423 886495
01423 889500
www.topseal.co.uk