Complete iMist™ Installation

This is what we would expect a complete iMist installation to look like.



Installation Component - Site Responsibility and Supply:

1.Plumbing - ¾ BSP Valve, Priority Demand Valve, Check Valve, Copper Feed Pipe - **These components can be purchased directly through iMist.**

2.Electrical – 32 AMP Rotary Main Switch, 32 AMP Rotary Switch, Unswitched Fuse Spur – (Neon Indicator), Fire Resistant Electrical Feed – (Cable) - **These components can be purchased directly through iMist.**

STX12-2 Domestic Pump requires 1 Bar and 14 Litres Per MINUTE

Please note: The above requirements are the customers responsibility

The above components are available to purchase directly from iMist
If you have any questions, please get in touch with your project co-ordinator and they will be able to assist